



- Use a DMX repeater on each 32nd fixture of the daisy chain or in case the total DMX cable length exceeds 1000 ft (300m).
- Insert a 120 Ω resistor connected to Data+ and Data- in the last unit.
- For further details on fixture connection and installation, please refer to the relevant instruction manual.

Description : GOBOLED 80 D - CONFIGURATION SCHEME

Code :

Scale : 1:8

Weight :

Revision : A-01

SHEET 1 OF 1

Note :

